

Tools with bold feed column no. are preferred choice.

Coolant:

- ☐ Air
- ☒ Neat oil
- ☐ Soluble oil

Cutting direction:

- ☒ right-hand cutting
- ☐ left-hand cutting

444

84503  
1897  
HSS-E  
F  
V  
83

445